Conference summary

Synchrotron light of the third and fourth generation - how to fill the generation gap

Friso van der Veen

Paul Scherrer Institut, Villigen, Switzerland

What have we learnt at this conference?

 that Howard Padmore and Joe Stöhr have put together an excellent conference program







Joe

that many presentations were of such a high level, that a summary of them is bound to fail.



Structure of the talk



3rd generation sources, FEL and ERL schemes




- Ultrashort X-ray pulses
 Time dependent processes
- Optics Microscopy, imaging
- Coherence
 Lensless imaging, interferometry,
 dynamical properties of matter
- Improved detection schemes
 We keep talking about it, but do too little!

Increased beam stability

Top-up injection at the SLS:

Top up also at APS and at future/upgraded sources



Top-up injection position stability

Position stability (σ)

100 s: 30 nm

20 days: $0.5 \mu m$

Year: $1-2 \mu m$


Energy stability ~10⁻⁵

Correcting the average hor, orbit by

adjusting the RF-frequency

FEL and ERL schemes

J. Hastings, T. Shintake, S. Gruner, many posters



Reduction of the gun emittance could strongly reduce the dimension of a FEL

$$\epsilon \leq \frac{\lambda}{4\pi}$$

$$\epsilon_{\mathsf{N}} = \epsilon \beta \gamma \longrightarrow \gamma \ge \frac{4\pi\epsilon_{\mathsf{N}}}{\lambda}$$

$$\rho^3 \approx \frac{I_{\text{peak}} \lambda}{\epsilon \gamma^2}$$

$$\lambda_U = \lambda \frac{2 \, \gamma^2}{1 + K^2 / 2}$$

- FOR DIFFRACTION LIMITED BEAM

- FOR REDUCED LINAC ENERGY

- FOR HIGHER FEL GAIN

- FOR SHORTER UNDULATOR LENGTHS

A possible way to reduce the emittance

Field emission gun


L. Rivkin

FIELD REQUIREMENTS ~ 5 V/nm → 5 GV/m


FIELD ENHANCEMENT OF A TIP:

$$E_{tip} = \frac{V}{k r}$$


for k~5, tip apex radius r=100 nm → V ~ 2kV




Generic field emitter array



Ultimate smallest tip built up by 4 tungsten atoms / H.-W. Fink, ETHZ



Use fs pulses for, e.g., lensless imaging of proteins



How long does it take for the molecule to fly apart?

S. Hau-Riege at Satellite Workshop on X-ray Science with Coherent Radiation:

Only about 4 fs!

→ Need coherent control in the time domain



More calculations of X-ray/matter interaction required


In the meantime: femtosecond electron beam slicing

R.W.Schoenlein et al.


Science 287 (2000), 2237

First taste of short pulses for experiments

- Use high pulse energy, fs lasers technology
- Undulator radiators
- 10² 10⁴ photons per pulse (low efficiency)




Beam slicing at the SLS



Intensities?

Current And Future X-Ray Sources



With pump-probe techniques one can accumulate signal. That helps.


Structure of the talk

- 3rd generation sources, FEL and ERL schemes
- Ultrashort X-ray pulses
 Time dependent processes



- Optics Microscopy, imaging
- Coherence
 Lensless imaging, interferometry,
 dynamical properties of matter
- Improved detection schemes
 We keep talking about it, but do too little!

Making small beam spots




P. Cloetens, C. Rau, C. Liu, A. Takeuchi, and others

Kirkpatrick-Baez optics:

- Achromatic
- Spot size is getting close to the diffraction limit $\lambda/(2 \cdot NA)$
- Alignment can be difficult

Refractive lenses



extreme curvature:

$$R = 1 \mu \text{m} - 3 \mu \text{m}$$

$$N = 50 - 100$$

Schroer et al., APL 82, 1485 (2003)


Refractive lenses:

- Chromatic
- Once installed, robust
- Much used for higher X-ray energies
- Can now be made out of 'plastic'
- Effective numerical aperture limited by Compton scattering

V. Nazmov, I. Snigireva, S.D. Shastri, and others

302004 25KV XİS.ÖK 2.ÖÖ W. Yun

Fresnel zone plates



Center and outer zones of a zone plate with 50 nm outer zone width and 700 um thickness.


Fresnel zone plates:


- Chromatic
- Soft X-ray microscopy
- Now also for hard X-rays (zones in anti-phase)

G. Schneider, W. Chao, Y. Suzuki, R. H. Menk Sr., B. Hornberger and many others

A special zone plate

Kipp et al.






"Photon sieve"

transmissive

reflective

These zone plates effectively remove subsidiary maxima in the focal plane enhanced contrast


Wedges and capillaries



Capillaries:

- Squeezes X-ray beams
- Become waveguides for small diameters
- Very small spot sizes are possible
- Coupling into the waveguide critical for efficiency

What is the smallest possible spot size?




with $\lambda = 1$ π

$$W_c = \frac{\lambda}{2\theta_c} = \frac{1}{2} \cdot \sqrt{\frac{\pi}{r_0 n_e}}$$


SiO₂: $\Delta x_{min} = 13 \text{ nm}$ Au: $\Delta x_{min} = 5 \text{ nm}$...this limit on spot size appears to hold also for other X-ray focusing devices.

Spectromicroscopic probes



Aberration corrected photoemission microscope

PEEM III at ALS:



At BESSY: SMART project


Features:

- Much higher transmission
- Spatial resolution of 5 nm, better than for XRM because of higher NA of electron objective lens


Time Resolved PEEM

S.B. Choe et al






Observation of magnetic vortex dynamics



CoFe Magnetic Pattern of 1 μ m x 1 μ m



Imaging of ultrafast spin dynamics with Magnetic soft X-ray Transmission Microscopy



microcoil

Δx=32 nm

Δx=32 nm


Δx=32 nm


x (nm)

3 μm

μ

sample: 4x4mm² PY element





- stroboscopic pump-and-probe technique
- high lateral resolution (<20nm) provided by FZP
- high temporal resolution given by SR pulse width (<100ps)
- inherent chemical sensitivity provided by XMCD magnetic contrast

Future: combine SXTM with streak camera


Structure of the talk


- 3rd generation sources, FEL and ERL schemes
- Ultrashort X-ray pulses
 Time dependent processes
- Optics Microscopy, imaging
- Coherence
 Lensless imaging, interferometry,
 dynamical properties of matter
- Improved detection schemes
 We keep talking about it, but do too little!




Fully coherent radiation.....

J.M. Byrd







Achieved at BESSY-II: 10⁴ more flux than from conventional IR sources

Plans for CIRCE @ ALS $10^6 - 10^{10}$ more flux


Coherent THz radiation

E.J. Singley, measurements performed at BESSY-II


THz Science:

- collective excitations
- superconductor gaps,
- protein motions & dynamics
- medical imaging

Near-field microspectroscopy on living objects



Superconductors




Note:


Near field microscopy not possible with X-rays, because matter behaves as dielectric for X-rays!

Using the partial coherence of an X-ray beam

Many contributions at the conference and at the workshop




Direct inversion of diffraction patterns or 'solving the phase problem'



Lensless imaging

See webpages of satellite workshop

Cluster of 50 nm gold balls



SEM image

Reconstructed image

J.H. Spence

General features:

- 3D reconstructions possible
- Depth of field in µm range, i.e. cell dimensions; much better than in TEM
- 10 nm resolution has been achieved
- Ultimate resolution depends on resistance to high radiation does

But note:

- Sofar only demonstration expts;
 but at Spring-8: on bacteria
 (J. Miao, T. Ichikawa et al)
- Electron microscopy still way ahead


Other uses of coherence

X-ray photon correlation spectroscopy

Studies of dynamics of (soft) condensed matter A. Madsen, G. Grübel et al

Note: extremely photon-hungry; accessible momentum range limited by count rate

- Phase contrast imaging, interferometry
 Many projects at the long beamlines of SPring-8, T. Ichikawa et al X-ray Fabry-Pérot for, e.g., metrology: Y. Shyd'ko
- Sub-ps coherent manipulation B.W. Adams Ultrafast X-ray switch?
- Coherent resonant magnetic scattering in soft X-ray range J. Lüning, J.B. Goedkoop Challenge: combine with ps dynamics of magnetic processes



Structure of the talk


- 3rd generation sources, FEL and ERL schemes
- Ultrashort X-ray pulses
 Time dependent processes
- Optics Microscopy, imaging
- Coherence
 Lensless imaging, interferometry,
 dynamical properties of matter




Improved detection schemes
We keep talking about it, but do too little!
Not true for G. Derbyshire

Pixel Detectors







Specs of SLS pixel detector
•Size: 40 x 40 cm2 (0.16m²)

■ 2000 x 2000 pixels

• Pixel size: 200 x 200 μm²

Modular detector -> dead area ~6%

High frame rate: >10Hz

High duty cycle: <6% (Tro~6ms)</p>

Next steps:


- Energy and time stamping
- Cross correlation of pixels in spatial and temporal domains

Major initiatives at several SR facilities are now underway

SLS pixel detector

PX at Spring-8, BL38B1


E. F. Eikenberry et al




X-rays

- Superconducting junction X-ray detectors
 S. Friedrich. Suited for fluorescence detection
- A special method for detecting moving biomolecules
 Y.C. Sasaki
- Inelastic soft X-ray scattering
 H.S. Fung: resolving power of 3x10⁴ at 400 eV!
 Other novel X-ray/VUV spectrometers: J. Guo, N. Kosugi, A. Tagliaferri, and C. Masciovecchio and others

Mn in oxygen-evolving complex in photosystem II





X-rays

- Superconducting junction X-ray detectors
 S. Friedrich. Suited for fluorescence detection
- A special method for detecting moving biomolecules
 Y.C. Sasaki
- Inelastic soft X-ray scattering
 H.S. Fung: resolving power of 3x10⁴ at 400 eV!
 Other novel X-ray/VUV spectrometers: J. Guo, N. Kosugi, A. Tagliaferri, and C. Masciovecchio and others

White X-ray (SR)

Gold nanocrystal

myosin

Diffracted X-ray

C-terminal


N-terminal

Electrons

High kinetic energy photoemission
 Important for bulk sensitivity in studies
 of electronic materials properties

 Y. Takata, G. Paolicelli
 Count rates very low!

New 1D and 2D electron detectors
 P. Denes




Probe depth @ 6 keV > 10nm Contribution of surface SiO₂ is negligible

Electrons


 High kinetic energy photoemission Important for bulk sensitivity in studies of electronic materials properties
 Y. Takata, G. Paolicelli Count rates very low!

New 1D and 2D electron detectors



- >2 GHz overall linear count-rate→
- spectral readout in 60 μs→
- time-resolved measurements
- programmable, robust
- Sized to fit existing spectrometers (Scienta, PHI, ...)

Spectacular growth of structural biology



Automation of PX facilities

C. Nave, M. D. Miller, N. K. Sauter

SSRL Beamline 11-1





SRS Daresbury

Need for standardization!

Filling the gap between the third and fourth generation

- We have no problem filling that gap!
- Each three years (SRI cycle) we win at least an order of magnitude in flux, brilliance, coherence, time resolution
- New SR facilities are very sophisticated
 Upgrades of existing facilities are underway
- The future of the next generation looks brilliant

The instrumentation scientists make it all happen!